



INSTALLATION IS AS EASY AS 1-2-3!

1. DRILL IT



Position grab bar as desired and determine location of studs. Mark outer edge of flange.



Align mounting plate with marks, mark center hole.



Drill 1 1/4" hole.

2. INSTALL IT



Insert guide sleeve.



Insert anchor with pull tab into guide sleeve.



Pull tab until anchor is tight, remove tab.

3. MOUNT IT



Attach mounting plate to anchor.



Attach grab bar flange to mounting plate.



Snap flange cover over flange.



CUSTOMER SERVICE USA: 1.800.882.0116 • FAX: 1.888.379.2720
INTERNATIONAL: 1.440.962.2263 • FAX: 1.440.962.2726
CANADA: 1.800.465.6130 • MEXICO: 1.800.718.4345
25300 Al Moen Dr. • North Olmsted, OH 44070 • 1.800.321.8809 • FAX: 1.800.848.6636
Visit our website at homecare.moen.com